

IMPORTANT! INSTALL "PONTIAC" LETTERS INDIVIDUALLY, NOT AS A GROUP, USING THE FOLLOWING GUIDELINES:

1. If possible, work at room temperature and not in full sun. Clean the area where the decals will be applied with rubbing alcohol. There must be NO oil or wax residue beneath the decals.
2. Fill any available clean spray bottle with water and add a few drops of liquid detergent to make a solution for applying decals. If a spray bottle is not available, use a bowl and apply the solution with a sponge.
3. Apply solution to the location where the decal will be placed.
4. Remove one letter from the backing material using a wet knife blade or similar clean object to lift and place the decal in position. The solution should be beneath the decal at this time. Try not to handle the decal with dry fingers (wet fingers are usually ok).
5. Position the decal as required. Repeated attempts may be needed and the solution will allow removal/replacement without damaging the adhesive. **Be careful not to fold the decal.**
6. When the decal is in position, press it down with a folded paper towel. This will absorb the water and will simultaneously squeeze water from behind the decal. Be careful not to shift the decal.
7. Place remaining letters in similar fashion.
8. Using the paper towel or a clean absorbent rag, lightly and carefully rub any decal which appears to have bubbles behind it until the bubbles disappear. It may be necessary to raise and replace a portion of a letter to achieve perfection.
9. With the water removed from the decals, it is safe to drive the car but it is best to wait a few hours for all water to evaporate just in case adhesion is weak. If you wish to drive immediately, probe the decals gently with a fingertip to confirm adhesion is sufficient.